В	BARI	BARISTA MENU			TECHNICIAN / SERVICE MENU *CHANGES TO TECHNICIAN / SERVICE MENU ARE NOT RECOMMENDED*				
	Gradual Soft Pre-Infusion (GSP) ON / OFF Ramp up: 2 - 30 seconds			6	Settings Password Protected Password default: 1-1-1				
					Customize Machine Name				
5	Brew Temperature Settings Adjust brew temp.			-	Eco Mode: ON / OFF				
	(\$\frac{1}{2}\)	<u> </u>			Set brew boiler temp after idle Set steam boiler temp after idle				
	,, ,								
eco	Eco Mode Settings Idle timer set			-	PID - Temp. Offset *CHANGES NOT RECOMMENDED*				
	eco		er set chine enters low power state	I _		Kp: <u>1.0</u>	Kd: <u>2.0</u>	Ki: <u>0.01</u>	
	z ^{zzz}		e standby set chine powers down	P		B: <u>2°C</u> / <u>4°F</u>	T	C / 16.2°F	
<u></u>	Boiler ON / OFF Selection				ক ্	Kp: <u>4.0</u>	Kd: <u>0.07</u>	Ki: <u>2.2</u>	
	•	Brew Boiler on / off				B: <u>5°C</u> / <u>9°F</u>			
	ড ্ব	Steam E	Boiler on / off		Pressure Profile Settings				
	Time / Date Adjustments				NON-FUNCTION FOR CREM ONE DUO V				
					GSP Pump Voltage				
<u>(</u> @)	Auto ON / OFF Settings • Function ON / OFF • When ON, each day of the week can be set to a				NON-FUNCTION FOR CREM ONE DUO V				
					Alert Settings				
	unique time frame • Setting power switch to OFF will override.			\triangle	After (X) brew cycles, alert displayed • Default setting 0				
	Shot Timer Screen Time • The total shot length remains on screen for the selected time interval • 0 - 30 seconds			l	•	NON-FUNCTION FOR CREM ONE DUO V			
				-	Boiler Priority				
				-_° <u>\</u>					
h	Machine Counters] 5					
		Machine Lifetime counters			Set Steam Boiler priority: Default				
	00%	<u></u>	Total liters of water used		Water Source Selection				
			Total shots pulled (min. 5sec)		✓ Use water reservoir				
	\triangle	User se	t counters		X	X Plumbed waterline connection			
		-	Liters since reset		D	NON-FUNCT	ION FOR CREM	M ONE DUO V	
I ÛI	Fahren	Shots pulled since reset Fahrenheit / Celsius Selection			Low Water Timeout Time machine will brew after low water Default 15sec				
				$\overline{\wedge}$	Voltage to Motor				
DMY	Date Format MM/DD/YY DD/MM/YY			Q.il	NON-FUNCTION FOR CREM ONE DUO V				
	YY/MM/DD USB Port Functionality				Steam Boiler Probe Sensitivity Default Medium Sensitivity				
	LOGO Download alternative logos			1	Installation Start-up • When engaged the Steam Boiler will fill. When the Steam Boiler is full, this icon will display • Raise the brew lever and allow water to flow for at least 90sect				
	Import pressure profiles from USB • Warning: Importing profiles will overwrite all existing profiles				Upload / Download Machine Settings				
					NON-FUNCTION FOR CREM ONE DUO V				
(<u>)</u>	Barista Knob Resolution • Adjustable from 0.2 - 0.5bar • Represent pressure change per knob click				Password Settings Change password from default 1-1-1				