

Barista Menu

Temperature Settings

- Hold right button to open temperature set
- **t1** will display
- Boiler temperature can now be adjusted
- **Left/Right** buttons to cycle
- Auto **Select** idle 5sec
- Offset brew temperature auto calculated



Boiler Heating Indicator

- Constant: Boiler heating
- Flashing: Boiler at temp.



Water Tank Empty

Technicians / Service Menu

Accessing Menu

- Turn the machine **OFF**
- Hold **Left** button while turning machine **ON**
- Hold until you see **F.01**
- **Left** button to cycle main menu options
- **Right** button to select main menu options
- **Left** and **Right** buttons to cycle sub-menu items
- Sub-menu items **Auto Select** after 5sec idle

F.01

Steam Boiler Timeout

- Default set to **90sec**

F.02

Non-Function for **CREM ONE HX PID**

F.03

Boiler Probe Sensitivity

- Default **Med**

F.04

Shot Timer

- Default **ON**

A.01

Water Source Selection

t

(Tank) Water Reservoir

n

(Network) Water Line

d

Disable

A.02

Low Water Timeout

- Time machine will brew after low water
- Default **15sec**

A.03

Non-Function for **CREM ONE HX PID**

h.02

Fahrenheit / Celsius Selection

PID Settings

MODIFICATIONS NOT RECOMMENDED

tP

td

ti

tb

E

Temperature Offset

- Default set **45°F / 7.2°C**